

# Functional performance of high-fill factor small-cell size SiPMs at FBK



*G. Paternoster, F. Acerbi, A. Ferri, A. Gola,  
C. Piemonte, G. Zappalà, N. Zorzi*

paternoster@fbk.eu



7<sup>th</sup> edition of the International Conference on New Developments  
In Photodetection - NDIP 14.  
July 2<sup>th</sup> 2014, Tours, France.

# Outline


- Introduction
- Standard SiPM technology at FBK
- High-Density (HD) SiPM Technology
- HD-SiPM Functional Characterization
- Application Example: TOF-PET
- Conclusions

# Standard SiPM technology at FBK

## RGB Technology

N-on-P structure


Peak sensitivity: Red-Green-Blue



## NUV Technology

P-on-N structure

Peak Sensitivity: Near Ultra Violet




Parameter
Breakdown voltage
Cell Size (Fill Factor)
DCR (20C)
DiCT
DeCT+AP
Max PDE band
Peak PDE

	RGB	NUV
Breakdown voltage	28.5 V	26.5 V
Cell Size (Fill Factor)	40 $\mu\text{m}$ (60%)	40 $\mu\text{m}$ (60%)
DCR (20C)	<400 kHz/mm <sup>2</sup>	100 kHz/mm <sup>2</sup>
DiCT	20%	<10%
DeCT+AP	15%	40%
Max PDE band	480-600 nm	300-400 nm
Peak PDE	35%	35%

# Standard RGB SiPM: limits

## 1. Limited fill factor $\rightarrow$ limited PDE



**Dead border region** around each SPAD deteriorates the active-to-total area ratio (FF).

The key-point to increase FF is the reduction of gap between high-field region and cell border

# Standard RGB SiPM: limits

## 2. Correlated noise

### ❖ Optical Cross-talk


CT can be reduced:

- with proper optical isolation structures;
- reducing the gain.

### ❖ After-pulsing

It can be reduced:


- reducing the carrier trapping centers;
- reducing the gain.




One way to reduce the gain is to reduce the Cell Size

# RGB-HD SiPM technology

Keeping the same active area of the Std. RGB technology, we redesigned the border structure to increase the FF



# RGB-HD SiPM technology



## Trench characteristics:


- Narrow ( $< 1 \mu\text{m}$ )
- High aspect-ratio (depth  $> 5 \mu\text{m}$ )
- Low roughness sides  
-> low induced defects

## Advantages:


- Optical isolation -> **Reduced Direct and Delayed Cross talk**
- Electrical isolation with reduced dead border width -> **Small Cell Size without FF reduction**

# RGB-HD SiPM technology

SiPM Cell, top view



	Std. SiPM RBG	RGB- HD
CS	40 $\mu\text{m}$	15 $\mu\text{m}$
FF	60 %	62 %





# Advantages of Small Cell Size

1. **Lower correlated noise**,  
because of lower gain (lower  $C_d$ ):

- lower afterpulsing
- lower direct and delayed CT
- lower external Optical CT (with scintillator).



Cell Size



Gain ( $10^5$ )



Correlated Noise

2. **Larger dynamic range, higher linearity**

3. **Faster recharge time**

- reduced pile-up
- useful with «slow» scintillators (CsI) for further dynamic range


4. **Operation at higher over-voltage** for

- better temperature stability
- better gain uniformity

# New SiPM-HD prototypes

Devices with five different CS have been produced and tested !

CS	Nominal FF	Cell Density
$12 \times 12 \mu\text{m}^2$	52 %	7056 cells/mm <sup>2</sup>
$15 \times 15 \mu\text{m}^2$	62 %	4624 cells/mm <sup>2</sup>
$20 \times 20 \mu\text{m}^2$	66 %	2500 cells/mm <sup>2</sup>
$25 \times 25 \mu\text{m}^2$	72 %	1600 cells/mm <sup>2</sup>
$30 \times 30 \mu\text{m}^2$	77 %	1156 cells/mm <sup>2</sup>



SiPM with 15 μm cell size

# RGB-HD SiPM Functional Characterization

## Main Parameters

- **Gain**
  - Number of electrons produced per detected photon
- **Correlated Noise**
  - after-pulsing, optical cross-talk
- **Primary Noise (DCR)**
  - Thermal+Tunneling generated events
- **Photo-detection efficiency (PDE)**
  - Number of detected photons over total incident photons

# RGB-HD SiPM Functional Characterization:

## GAIN

**Std. SiPM RGB  
(CS 40  $\mu\text{m}$ )**


**Gain =  $4 \cdot 10^6$**

**FF 60 %**

**RGB-HD  
(CS 15  $\mu\text{m}$ )**

**Gain =  $4 \cdot 10^5$**


**FF = 62 %**



**20°C, OV= 4 Volts**

# Crosstalk Probability

<b>Std. SiPM RGB (40 <math>\mu\text{m}</math>)</b>
<b>CT = 20 %</b>
<b>FF = 60 %</b>
<b>RGB-HD (15<math>\mu\text{m}</math>)</b>
<b>CT &lt; 5 %</b>
<b>FF = 62 %</b>



20°C, OV= 4 Volts

# RGB-HD SiPM Functional Characterization: Dark Count Rate (DCR)

**Std. SiPM RGB  
(40 $\mu$ m)**


**DCR = 200-400  
kHz/mm<sup>2</sup>**

**FF 60 %**

**RGB-HD (15 $\mu$ m)**


**DCR= 250  
kHz/mm<sup>2</sup>**

**FF = 62 %**




**20°C, OV= 4 Volts**


# Photo Detection Efficiency (PDE)



$\lambda = 590 \text{ nm}$



# Max Photo Detection Efficiency with Cross-talk & after-pulsing < 10%




20,25,30um cells  
are equivalent!

Devices working at high OV have higher temperature stability




# RGB-HD for TOF-PET (1)

Energy Resolution @ 511keV




4x4mm<sup>2</sup> **SiPM-HD** with 25μm cell  
coupled to  
3x3x5mm<sup>3</sup> LYSO (teflon wrapped)




Excellent energy  
resolution  
(corrected for  
non-linearity)

# RGB-HD for TOF-PET (2)

## Coincidence Time Resolution



- 2 4x4mm<sup>2</sup> SiPMs-HD each coupled to
- 3x3x5mm<sup>3</sup> LYSO (teflon wrapped) in coincidence
- Leading edge discriminator



RGB-HD shows impressive time resolution because of high PDE

<b>RGB-HD (CS=25µm)</b>
<b>CRT @ -20°C = 130 ps</b>
<b>CRT @ +20°C = 145 ps</b>

# Conclusion

- A new border structure in cell design allowed to obtain SiPM with **small CS** and **high FF**.
- The new devices have been characterized in terms of PDE and noise characteristics
- Very promising results with **HD technology** in terms of **PDE** and **Correlated noise**.
- Very promising results for **TOF-PET** applications (good **energy resolution** and **coincidence time resolution**)

# Future Development

- We're already implementing **new technological features** to further increase FF and reduce the crosstalk.
- Development of **NUV-HD** technology SiPM with PDE peaked in UV region

# Thanks for your attention !!!

## ... and thanks to all collaborators



Fabio Acerbi  
Pierluigi Bellutti  
Alessandro Ferri  
Gabriele Giacomini  
Alberto Gola  
Giovanni Paternoster  
Antonino Picciotto  
Gaetano Zappala'  
Nicola Zorzi



Patrick Bouvier  
Sabrina Colpo  
Alfredo Maglione  
Nicola Serra  
Alessandro Tarolli  
Nicola Fronza